


Quick-Start Guide

1. Start with a clean tub, and new or clean filter cartridge(s).
2. Fill spa with fresh water and operate circulating pump.
3. Test water with Bromine 4-in-1 test strips; adjust if necessary using Alkalinity Increaser or pH Decrease. Total Alkalinity should be 80-120 ppm and pH between 7.2-7.6. Read all package instructions for more information. Recheck weekly.
4. Water hardness: If below 150 ppm, add Hardness Increaser to attain at least that level. Ideal range is between 150 - 300 ppm.
5. Add Sea Klear Natural Clarifier at the rate of 1 oz./500 gallons weekly.
6. Add Metal Free stain/metal preventer per label directions.
7. Shock water weekly with Oxy-Spa non-chlorine MPS shock at the rate of 1 1/2 - 2 oz. per 500 gallons. (1 1/2 tablespoons = approx. 2 oz.)
8. Add Granular Bromine Booster per label directions to establish an immediate bromine reserve or bank of 1.0 to 2.0 ppm.
9. Adjust cartridges per package directions (mineral wide open at #6. Set bromine to #5 setting for the first 24 hours only). Insert into floating holder. 
10. Keep ZorbO in spa to absorb oil scum (replace every 3-6 months).
11. Allow water to circulate to equilibrate spa chemicals for an hour or two (or overnight) then retest with test strips; readjust water balance if necessary.

NOTES:

- Drain spa, clean filters and repeat startup procedure every 2 to 4 months, depending on bather load.
- Always apply chemicals separately— never combine them prior to addition to the spa water.
- Adjust bromine setting down after 24 hours to maintain a low 1.0 to 2.0 ppm.
- Read all package directions for additional information.

Reorder list:

Bromine Cartridge #CA1044

Metal Free #CA1064

Mineral Cartridge #CA1045

Bromine 4-in-1 Test Strips #TB1006

Bromine Booster #CA1010

Sea Klear Clarifier #CA1013

Oxy Spa #CA1021

Hardness Increaser #CA1020

Alkalinity Increaser #CA1017

pH Decrease #CA1018

ZorbO Oil Scum Absorber #MT1052